

## Fitting Instructions – Atlantic Traditional Hat And Coat Hook

# AHCH

Date Modified: 16/08/2022

Last modified by: Alice W

For best results when fixing a hat and coat hook follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

X1 Hat and Coat Hook

X4 Screws

- 1) First, mark out the desired position for the hook on the wall/door.
- 2) Then, position the hook in the desired location and mark out the x4 screw holes. Then remove.
- 3) Next, pilot hole for the screws with a 2mm drill bit.
- 4) Now, place the hook back in the desired location, making sure the screw holes are aligned and screw into place using the provided screws.