

Fitting Instructions – Atlantic T Bar Pull Handle (bolt through) 600mm x 32mm

APH60032TBAR

Date Modified: 17/08/2022

Last modified by: Brock H

For best results when fixing a finger plate follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Note: Atlantic UK recommends fitting a T Bar Pull Handle before fixing a push plate.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

X1 T Bar

X2 Bolts

- 1) First, mark out the desired position of the T Bar on the pull side of the door. Mark out your hole centers to match up with the threaded holes on the T Bar.
- 2) Then, drill out the counterbore for the head of the bolt using a 12mm bit.
- 3) Now, fully drill the hole all the way through the door using an appropriate drill bit allowing the bolt to pass through.
- 4) Next, place the bolts in the holes.
- 5) Finally, offer up the T Bar to the bolts and secure in place.