

Fitting Instructions – ACRA Atlantic heavy duty roller catch

ARCA Adjustable Heavy Duty Roller Catch

Date Modified: 23/05/2023

Last modified by: Brock Hutchins

For best results when fixing an ARCA roller catch follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

- 1) Separate out all components supplied as follows:
 - X1 Roller Catch
 - X1 Face Plate
 - X1 Strike Plate
 - X4 Screws
- 2) First, mark out the desired position for the Catch on the door.
- 3) Next, router out a hole for the catch to sit in (including a space for the faceplate).
- 4) Insert the catch into the pre-routed hole (ensuring that the beveled edge of the latch is facing toward the frame rebate), insert the faceplate onto the latch using 2 of the screws provided to secure the door.
- 5) Now, mark out the position of the catch roller on the frame.
- 6) Offer the strike plate over the marked position and draw around the outline.
- 7) Next, cut out that marked area (allowing space for the roller to sit) in the door.
- 8) Insert the strike plate and secure it with the remaining 2 screws provided.
- 9) Test and adjust as necessary to make the fit correct.
- 10) If you need to make the roller protrude or retract, there is a screw in the back of the body that can be tightened or released as needed to make this happen. **YOU WILL NEED TO REMOVE THE CATCH FROM THE DOOR TO BE ABLE TO MAKE THESE ADJUSTMENTS.**