

Forme Fitting Instructions – Lever on back plate

Forme – Lever on back plate

Date Modified: 12/06/2021

Last modified by: Alice W

For best results when fixing Forme levers on backplate, follow these instructions.

Box should contain:

- X2 Levers
 - Fixing pack (x2 grub screws, x4 screws, 1x 3mm a key, spindle)
1. Mark the door for lock and install the lock.
 2. Place spindle in the lock, ensuring cut out is down.
 3. Offer up a lever plate to the door, ensuring it is parallel to the edge of the door. Make sure key aperture lines with lock.
 4. Drill pilot holes for screw.
 5. Insert screws provided.
 6. Repeat the process for the opposite lever.
 7. Install the grub screw in the bottom of the lever with the supplied fixings.